

DISMANTLING PROCEDURE

This product should be dismantled for disposal when it reaches the end of its life. Ensure that the electrical supply is disconnected before removal from the installation. Consult a qualified electrician if in any doubt.

Product type:	Panel lights
Product codes:	CPLxxCT, CPLxxWCT
Dismantling procedure:	
<ol style="list-style-type: none"> 1. Remove the fixing bracket by inserting a flat screwdriver beneath and levering away from the luminaire 2. Cut through or unscrew and remove the safety wire 3. Remove the screws on the rear of the luminaire and separate the bezel 4. Remove the opaque white reflector, clear diffuser and opal diffuser from the bezel 5. Remove remaining metal clips and magnets from the bezel 6. Remove the light source and CCT switch from the luminaire rear cover 	
Recycling material:	
Bracket	Metal
Safety wire	
Metal clips	
Screws	
Bezel	Plastic
Rear cover	
Diffusers	
Light source	Electrical goods
CCT switch	
Reflector	Non-recyclable

Advice from local recycling facilities should be sought as to specific types of waste which may be accepted.