

DISMANTLING PROCEDURE

This product should be dismantled for disposal when it reaches the end of its life. Ensure that the electrical supply is disconnected before removal from the installation. Consult a qualified electrician if in any doubt.

Product type:	Outdoor wall lights
Product codes:	LWRxx~LWSxx, RWLxx
Dismantling procedure:	
<ol style="list-style-type: none"> 1. Remove the mounting bracket from the luminaire with an Allen key 2. Unscrew and remove the backplate and cable entry grommet 3. Lift out the PCB and LED strip 	
Recycling material:	
Luminaire housing	Metal
Bracket	
Screws	
Backplate	Plastic
PCB and LED strip	Electrical goods
Grommet	Non-recyclable

Advice from local recycling facilities should be sought as to specific types of waste which may be accepted.