

INSTALLATION & MAINTENANCE MANUAL **EVOC series**











GENERAL INSTRUCTIONS

These instructions should be read carefully and retained after installation by the end user for future reference and maintenance.

These instructions should be used to aid installation of the following products:

EVOCW, EVOCC, EVOCBC

SAFETY

- Installation of this hole converter should only be carried out by a qualified electrician or competent person to the latest Building and current IEE Wiring Regulations (BS7671)
- Please isolate mains prior to installation/maintenance
- Please note the IP (Ingress of Protection) rating of this hole converter when deciding the location for installation
- This product is IP20 rated

INSTALLATION

• We recommend that this hole converter is used for holes between 80mm and a maximum of 135mm (see Fig 1)





Fig 1

• Pull back the spring clips and place the EVOICF fitting into the hole converter (EVOC_) (see Fig 2)



• With the EVOC_ and the EVOICF together in position, place into the cut-out




Fig 3

Fig 2

• Switch on and test for correct operation

GENERAL

The unit should be recycled in the correct manner when it reaches the end of its life. Check local authorities for where facilities exist.

Clean with a soft dry cloth only, do not use aggressive cleaning products or solvents which may damage the fitting.

WARRANTY

This product has a warranty of 1 year from date of purchase. Failure to install this product in accordance with the current edition of the IEE Wiring Regulations, improper use, or removal of the batch codes will invalidate the warranty. If this product should fail within its warranty period it should be returned to the place of purchase for a free of charge replacement. ML Accessories does not accept responsibility for any installation costs associated with the replacement product. Your statutory rights are not affected. ML Accessories reserve the right to alter product specification without prior notice.