



LET'S GET
YOU SET UP

USER GUIDE



Download the SmartKnight App

On Google Play (Android™) or App Store® (Apple®).
Open the app, tap "Register" and follow the on-screen instructions



Add Device

(2.4 Ghz only)

To add a device tap the "+" on top right corner, select the product category and follow the on-screen instructions



Enjoy

Enjoy your connected product. For more in-depth instructions, please see section titled "Wi-Fi Control" in this leaflet



INSTALLATION & MAINTENANCE MANUAL

OSMKW

GENERAL INSTRUCTIONS

These instructions should be read carefully and retained after installation by the end-user for future reference and maintenance.

**These instructions should be used to aid the installation of the following product:
OSMKW**

SAFETY

- Please note the IP (Ingress Protection) rating of this product when deciding the location for installation
- This product is IP20 rated

INSTALLATION

Note: Please avoid installing the sensor within the proximity of reflective surfaces, direct airflow from vents, fans, windows, sources of steam, infrared light sources and objects causing changes of temperatures like heaters, refrigerators, and ovens.

- Ensuring not to infringe with any gas / water pipes or electrical cables drill a hole into the installation area and affix the magnet with the included fixing screw and wall plug (see Fig.1)




Fig. 1

Note: We recommend a walk test be carried out after the installation to ensure the desired area is covered, if not, the angle of the sensor can be adjusted to obtain the desired detection area

BATTERY INSTALLATION

- Using the included screwdriver, unscrew the back of the sensor, replace the batteries ensuring the correct polarity is observed, and re-fit the back of the sensor (see Fig. 2)




Fig. 2

WI-FI CONTROL

- Download the SmartKnight app on Google Play or the App Store
- Once the app is downloaded, open the app and tap "Register" then follow the on-screen instructions
- To add a sensor to the app, ensure that the sensor is powered and tap "+" on the top right corner
- Tap "Motion Sensor"
- If the indicator is flashing rapidly, please skip the reset procedure and tap "Confirm the indicator is flashing rapidly". If the indicator is not flashing, follow the on-screen instructions to reset it
- Connect to the desired Wi-Fi network, tap "Confirm" and the app will start searching for devices. Please note only 2.4 GHz networks are supported and make sure your device is connected to the same Wi-Fi network
- After the sensor has been added successfully to the app, it can be named and added to a room. After naming it, tap "Done"

GENERAL

This product should be recycled in the correct manner when it reaches the end of its life. Check local authorities for where facilities exist.

The batteries in this sensor are Alkaline and must be disposed of correctly. Please contact the local authorities for the disposal of this toxic waste

WARRANTY

This product has a warranty of 2 years (excluding battery) from date of purchase. Improper use or removal of the batch code will invalidate the warranty. If this product should fail within its warranty period it should be returned to the place of purchase for a free of charge replacement. ML Accessories does not accept responsibility for any installation costs associated with the replacement product. Your statutory rights are not affected. ML Accessories reserve the right to alter product specification without prior notice.



ML Accessories Limited LU5 4LT

www.mlaccessories.co.uk

AVJUN20_V1