Knightsbridge

These instructions should be read carefully and retained after installation by the end user for future reference and maintenance.

SAFETY

This product must be installed in accordance with the latest edition of the IEE Wiring Regulations (BS 7671) and current Building Regulations. If in any doubt, consult a qualified electrician.

Please isolate mains prior to installation or maintenance

Check the total load on the circuit (including when this products fitted) does not exceed the rating of the circuit cable, fuse or circuit breaker Do not overload this accessory or subject t to conditions outside its rating

This product is for indoor use only

FOR A PERFECT INSTALL

Always ensure the wall surface is flat and smooth Install accessories after all painting and decorating is complete

Wire as per the instructions in this wiring guide and fix plate to the back box using the screws provided. Apply screw cap covers if desired.

METAL CLAD FIXING

Separate the front faceplate and rear mounting box and mount the rear box in a suitable location. The box has multiple 20mm cable entry points to aid installation

Wire as per the instructions in this wiring guide and fix plate to the back box using the screws provided.

USB CHARGING FUNCTION

We offer a variety of USB charging within our range, and all are designed for charging portable USB devices only, they feature short circuit and overload/overheat protection.

We recommend to only use certified USB cables when charging for optimum performance.

If you experience no power on the USB, disconnect any device ensure the sockets have not encountered liquid or debris and the device is not damaged or overheating. With nothing connected, the USB outlet will automatically reset and be available for use.

WARNING

Dimmers, and accessories with LED or neon indicators must be disconnected from the circuit prior to any high voltage or insulation resistance testing.

To avoid risk of damage to sensitive USB circuitry: Max. Insulation Resistance Test: 250V DC

Failure to do so could cause irreparable damage and void warranty.

GENERAL

This product should be recycled in the correct manner when it reaches the end of its life. Check local authorities for local disposal facilitates

CARE AND MAINTENANCE

Clean with a soft dry cloth only, do not use chemical cleaning products or solvents as they may damage accessories and invalidate the warranty.

WARRANTY

Knightsbridge Wiring Accessories have a warranty of 25 years for mechanical operation from the date of purchase with the exception of products containing electronic components such as dimmers and USB accessories which have a 2-year warranty.

Failure to install this product in accordance with the current edition of the IEE Wiring Regulations (BS 7671), improper use, improper testing, or removal of the batch code will invalidate the warranty.

If this accessory should fail withing its warranty period, it should be returned to the place of purchase for a free of charge replacement.

ML Accessories does not accept responsibility for any installation costs associated with the replacement product.

Your statutory rights are not affected

ML Accessories reserve the right to alter product specifications without prior notice

INSTALLATION

Connect the accessory as per the diagram in this wiring guide, ensuing the correct polarity is observed

L – LIVE – BROWN

N – NEUTRAL – BLUE

EARTH – GREEN/YELLOW sleeve

All earth connection must be made and maintained. Use green/yellow sleeving on earth conductors that are not insulated

Check all electrical connections are secure with all exposed copper within the terminal and no loose strands of cable

If using the flex outlet options, ensure the flex is secured with the cord grip provided

Fit the accessory into a suitable wall box taking care not to compress, damage or trap any cables, and secure with the screws provided.

If using metal mounting boxes with four lugs, remove or bend fully back the top and bottom lugs to prevent them inhibiting the installation

Supplied by:
(UK) Manufacturer ML Accessories Ltd, Unit E Chiltern Park, Boscombe Road, Dunstable LU5 4LT www.mlaccessories.co.uk
(EU) SLV Lighting Group, DaimlerstraÊe 21-23, 52531 Ubach–Palenberg, Germany Email: eprel@group.slv.com
Made in China


13A 1G SOCKET
FROM SUPPLY
13A 2G DP SWITCHED SOCKET WITH OUTBOARD ROCKERS
TO FUSE BOX, EARTH
13A 1G SOCKET WITH USB OUTLET
13A 2G SOCKET WITH USB OUTLET
13A 1-GANG DP SOCKET WITH USB OUTLET
13A 2 GANG DP SOCKET WITH DUAL OUTBOARD USB
13A 2G SWITCHED SOCKET WITH OUTBOARD ROCKERS AND DUAL USB
13A 1 GANG DP LOCKABLE SOCKET
KEYS REMOVED
KEYS IN
Ensure the electrical connections are tight, including those of the pre-installed back box.
20A DP LOCKABLE SWITCH
SHAVER SOCKET
5A 1G SOCKET
FUSE CONNECTION UNIT
SWITCHED FUSE CONNECTION UNIT
20A SWITCH
20A FLEX OUTLET
45A SWITCH
TO COOKER
COOKER CONTROL UNIT
45A COOKER OUTLET
TV SOCKET
SHAVER/RAZOR CHECK LAMP
CLAMP CENTRE CONDUCTOR UNDER TERMINAL
10A 1-WAY CEILING SWITCH
TO LIGHT
10A 2-WAY CEILING SWITCH
2-WAY SWITCH
45A CEILING SWITCH
4-WAY JUNCTION BOX
SWITCHED (RED/BLUE) MUST HAVE BROWN SLEEVE
Cable Restraints
BATTEN HOLDERS, CEILING ROSE & PENDANT SETS
Looping Circuit
Junction Box Circuit
TO PENDANT
SWITCHED (RED/BLUE) MUST HAVE BROWN SLEEVE
PLUG IN CEILING ROSE
How to open the plug.
Push
3 TERMINAL VERSION
Pendant Switch
LCS PLUG
Luminaire
Mains Supply
4 TERMINAL VERSION
Emergency Luminaire
Unswitched Live
Switched Live