Knightsbridge

These instructions should be read carefully and retained after installation by the end user for future reference and maintenance.

This product must be installed in accordance with the latest edition of the IEE Wiring Regulations (BS 7671) and current Building Regulations. If in any doubt, consult a gualified electrician. Please isolate mains prior to installation or maintenance

Check the total load on the circuit (including when this product s fitted) does not exceed the rating of the circuit cable, fuse or circuit breaker

Do not overload this accessory or subject t to conditions outside its rating

This product is for indoor use only

FOR A PERFECT INSTALL

Always ensure the wall surface is flat and smooth

These accessories are fitted with an integral gasket to prevent discolouration of the plate due to

natural moisture in some wall finishes.

The box has multiple 20mm cable entry points to aid installation

Install accessories after all painting and decorating is complete

Wire as per the instructions in this wiring guide and fix plate to the back box using the screws

METAL CLAD FIXING

Separate the front faceplate and rear mounting box and mount the rear box in a suitable location

Wire as per the instructions in this wiring guide and fix plate to the back box using the screws provided.

authorities for local disposal facilitates

CARE AND MAINTENANCE n with a soft dry cloth only, do not use chemical cleaning products or solvents as they may damage the finish or protective coatings applied to the accessories and invalidate the warranty.

Knightsbridge Wiring Accessories have a warranty of 25 years for mechanical operation from the date of purchase with the exception of products containing electronic components such as dimmers and USB accessories which have a 2-year warranty.

7671), improper use, improper testing, or removal of the batch code will invalidate the warranty. If this accessory should fail withing its warranty period, it should be returned to the place of purchase liquid or debris and the device is not damaged or overheating. With nothing connected, the USB outlet will for a free of charge replacement.

ML Accessories does not accept responsibility for any installation costs associated with the

replacement product.

Your statutory rights are not affected

ML Accessories reserve the right to alter product specifications without prior notice

devices only, they feature short circuit and overload/overheat protection.

the small notch on either side of accessory and gently lever off on both sides. Store front plate safely.

fitting to the wall box, take care not to overtighten and once everything is flush to wall and secure clip the

NB: If you need to substitute the screws provided with longer length ones - ensure they are flat head

We offer a variety of USB charging within our range, and all are designed for charging portable USB

If you experience no power on the USB, disconnect any device ensure the sockets have not encountered

Dimmers, and accessories with LED or neon indicators must be disconnected from the circuit prior to any

After wiring, ensure the plastic gasket is fully clipped back on to the main body and proceed to mou

countersunk M3.5 screws, any other screws the heads will inhibit the front plate from sitting flat.

We recommend to only use certified USB cables when charging for optimum performance.

high voltage or insulation resistance testing.

automatically reset and be available for use.

To avoid risk of damage to sensitive USB circuitry:

SCREWLESS FIXING

front plate back into position gently.

USB CHARGING FUNCTION

WARNING

Max. Insulation Resistance Test: 250V DC Failure to do so could cause irreparable damage and void warranty. INSTALLATION

Connect the accessory as per the diagram in this wiring guide, ensuing the correct polarity is observed.

L - LIVE - BROWN N - NEUTRAL - BLUE EARTH - GREEN/YELLOW sleeve

All earth connection must be made and maintained. Use green/yellow sleeving on earth conductors

that are not insulated Check all electrical connections are secure with all exposed copper within the terminal and no loose strands of cable If using the flex outlet options, ensure the flex is secured with the cord grip provided

Fit the accessory into a suitable wall box taking care not to compress, damage or trap any cables, and secure with the screws provided. If using metal mounting boxes with four lugs, remove or bend fully back the top and bottom lugs to prevent them inhibiting the installation

(UK) Manufacturer ML Accessories Ltd, Unit E Chiltern Park, Boscombe Road, Dunstable LU5 4LT www.mlaccessories.co.uk

(EU) SLV Lighting Group, Daimlerstraße 21-23, 52531 Übach-Palenberg, Germany Email: eprel@group.slv.com Made in China

13A SWITCHED SOCKETS

13A SOCKETS WITH USB

10AX 2-WAY SWITCH

10AX INTERMEDIATE LIGHT SWITCH



